LG
Life's Good

PLASMA TV
OWNER'S MANUAL

42PQ20	42PQ60
50PQ20	50PQ60
42PQ30	50PS30
50PQ30	50PS60
	60PS60

Please read this manual carefully before operating your set and retain it for future reference.
The model and serial number of the TV is located on the back and one side of the TV.
Record it below should you ever need service.

Model:

Serial:

ENERGY STAR

This product qualifies for ENERGY STAR in the "factory default (Home Use mode)" setting and this is the setting in which power savings will be achieved.

Changing the factory default picture setting or enabling other features will increase power consumption that could exceed the limits necessary to quality for Energy Star rating.

1-800-243-0000 USA, Consumer User
1-888-865-3026 USA, Commercial User
1-888-542-2623 CANADA
LG Customer Information Center

P/NO : SAC33575901(0901-REV02)

WARNING / CAUTION

TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING/CAUTION

TO REDUCE THE RISK OF FIRE AND ELECTRIC SHOCK, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

NOTE TO CABLE/TV INSTALLER

This reminder is provided to call the CATV system installer’s attention to Article 820-40 of the National Electric Code (U.S.A.). The code provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of the cable entry as practical.

WARNING / CAUTION

To prevent fire or shock hazards, do not expose this product to rain or moisture.

FCC NOTICE

Class B digital device

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

CAUTION

Do not attempt to modify this product in any way without written authorization from LG Electronics. Unauthorized modification could void the user’s authority to operate this product

SAFETY INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS

Read these instructions.
Keep these instructions.
Heed all warnings.
Follow all instructions.

1. Do not use this apparatus near water.



2. Clean only with dry cloth.

3. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.



4. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers)that produce heat.

5. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong, The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.



6. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.



7. Only use attachments/accessories specified by the manufacturer.

8. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



9. Unplug this apparatus during lighting storms or when unused for long periods of time.



10. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



SAFETY INSTRUCTIONS

11 Never touch this apparatus or antenna during a thunder or lighting storm.

12 When mounting a TV on the wall, make sure not to install the TV by the hanging power and signal cables on the back of the TV.

13 Do not allow an impact shock or any objects to fall into the product, and do not drop onto the screen with something.

14 CAUTION concerning the Power Cord:

It is recommend that appliances be placed upon a dedicated circuit; that is, a single outlet circuit which powers only that appliance and has no additional outlets or branch circuits. Check the specification page of this owner's manual to be certain.

Do not connect too many appliances to the same AC power outlet as this could result in fire or electric shock.

Do not overload wall outlets. Overloaded wall outlets, loose or damaged wall outlets, extension cords, frayed power cords, or damaged or cracked wire insulation are dangerous. Any of these conditions could result in electric shock or fire. Periodically examine the cord of your appliance, and if its appearance indicates damage or deterioration, unplug it, discontinue use of the appliance, and have the cord replaced with an exact replacement part by an authorized servicer. Protect the power cord from physical or mechanical abuse, such as being twisted, kinked, pinched, closed in a door, or walked upon. Pay particular attention to plugs, wall outlets, and the point where the cord exits the appliance.

Do not make the TV with the power cord plugged in. Do not use a damaged or loose power cord. Be sure do grasp the plug when unplugging the power cord. Do not pull on the power cord to unplug the TV.

15 WARNING - To reduce the risk of fire or electrical shock, do not expose this product to rain, moisture or other liquids. Do not touch the TV with wet hands. Do not install this product near flammable objects such as gasoline or candles or expose the TV to direct air conditioning.

16 Do not expose to dripping or splashing and do not place objects filled with liquids, such as vases, cups, etc. on or over the apparatus (e.g. on shelves above the unit).

17 GROUNDING

Ensure that you connect the earth ground wire to prevent possible electric shock (i.e. a TV with a three-prong grounded AC plug must be connected to a three-prong grounded AC outlet). If grounding methods are not possible, have a qualified electrician install a separate circuit breaker.

Do not try to ground the unit by connecting it to telephone wires, lightening rods, or gas pipes.



18 DISCONNECTING DEVICE FROM MAINS

Mains plug is the disconnecting device. The plug must remain readily operable.

19 "As long as this unit is connected to the AC wall outlet, it is not disconnected from the AC power source even if you turn off this unit by SWITCH"

20 ANTENNAS

Outdoor antenna grounding

If an outdoor antenna is installed, follow the precautions below. An outdoor antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can come in contact with such power lines or circuits as death or serious injury can occur.

Be sure the antenna system is grounded so as to provide some protection against voltage surges and built-up static charges.

Section 810 of the National Electrical Code (NEC) in the U.S.A. provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes and requirements for the grounding electrode.

Antenna grounding according to the National Electrical Code, ANSI/NFPA 70


Ground Clamp
Antenna Lead in Wire
Antenna Discharge Unit (NEC Section 810-20)
Grounding Conductor (NEC Section 810-21)
Electric Service Equipment
Ground Clamps
Power Service Grounding Electrode System (NEC Art 250, Part H)

NEC: National Electrical Code

21 Cleaning

When cleaning, unplug the power cord and scrub gently with a soft cloth to prevent scratching. Do not spray water or other liquids directly on the TV as electric shock may occur. Do not clean with chemicals such as alcohol, thinners or benzene.

22 Moving

Make sure the product is turned off, unplugged and all cables have been removed. It may take 2 or more people to carry larger TVs. Do not press against or put stress on the front panel of the TV.

23 Ventilation

Install your TV where there is proper ventilation. Do not install in a confined space such as a bookcase. Do not cover the product with cloth or other materials (e.g.) plastic while plugged in. Do not install in excessively dusty places.

24

If you smell smoke or other odors coming from the TV or hear strange sounds, unplug the power cord contact an authorized service center.

25

Do not press strongly upon the panel with hand or sharp object such as nail, pencil or pen, or make a scratch on it.



26

Keep the product away from direct sunlight.

CONTENTS

WARNING / CAUTION ..... A
SAFETY INSTRUCTIONS 1
FEATURE OF THIS TV 6

PREPARATION

Accessories 7
Front Panel Information 8
Back Panel Information 10
Stand Instruction 11
Desktop Pedestal Installation 12
Swivel Stand 12
Cable Arrangement 12
VESA Wall Mounting 13
Securing the TV to the wall to prevent falling when the TV is used on a stand 14
Antenna or Cable Connection 15

EXTERNAL EQUIPMENT SETUP

HD Receiver Setup 16
DVD Setup 19
VCR Setup 21
Other A/V Source Setup 23
Audio Out Connection 23
USB Connection 24
PC Setup 25

WATCHING TV / CHANNEL CONTROL

Remote Control Functions 30
Turning On TV 34
Channel Selection 34
Volume Adjustment 34
Initial Setting 35
On-Screen Menus Selection 37
Quick Menu 38
Channel Setup
- Auto Scan (Auto Tuning) 39
- Add / Delete Channel (Manual Tuning) 40
- Channel Editing 41
Channel List 42
Favorite Channel Setup 43
Favorite Channel List 43
Brief Information 44
Input List 45
Input Label 46
AV Mode 47
SIMPLINK 48

USB

Entry Modes 50
Photo List 51
Music List 55

PICTURE CONTROL

Picture Size (Aspect Ratio) Control 58
Energy Saving 61
Preset Picture Settings(Picture Mode) 62
Manual Picture Adjustment - User Mode 63
Picture Improvement Technology 64
Expert Picture Control 65
Picture Reset 68
Image Sticking Minimization (ISM) Method 69
Demo Mode 70

SOUND & LANGUAGE CONTROL

Auto Volume Leveler (Auto Volume) 71
Clear Voice II 72
Preset Sound Settings (Sound Mode) 73
Sound Setting Adjustment - User Mode 74
Balance 75
TV Speakers On/Off Setup 76
Audio Reset 77
Stereo/SAP Broadcasts Setup 78
Audio Language 79
On-Screen Menus Language Selection 80
Caption Mode
- Analog Broadcasting System Captions 81
- Digital Broadcasting System Captions 82
- Caption Option 83

TIME SETTING

Clock Setting
- Auto Clock Setup 84
- Manual Clock Setup 85
Auto On/Off Time Setting 86
Sleep Timer Setting 87

PARENTAL CONTROL / RATINGS

Set Password & Lock System 88
Channel Blocking 91
Movie & TV Rating 92
Downloadable Rating 97
External Input Blocking 98
Key lock 99

APPENDIX

Troubleshooting 100
Maintenance 102
Product Specifications 103
Programming The Remote Control 104
IR Codes 107
External Control Through RS-232C 109

FEATURE OF THIS TV

- This feature is not available for all models.

SRS is a trademark of SRS Labs, Inc.
TruSurround XT technology is incorporated under license from SRS Labs, Inc.

THX Cinema mode is recommended for watching movies. Designed for use in a dark room.
(This feature is not available for all models.)

High-definition television. High-resolution digital television broadcast and playback system composed of roughly a million or more pixels, 16:9 aspect-ratio screens, and AC3 digital audio. A subset of digital television, HDTV formats include 1080i and 720p resolutions.

Manufactured under license from Dolby Laboratories. "*Dolby* "and the double-D symbol are trademarks of Dolby Laboratories.

This TV contains the detailed calibrations necessary for professional certification by the Imaging Science Foundation. The resulting ISF "day" and "night" modes will then be accessible by the user to experience the best their LG HDTV has to offer.
CALIBRATE LIKE A PRO: Sophisticated and detailed calibrations can be made through the ISFccc mode. Detailed calibration requires a licensed technician. Please contact your local dealer to inquire about an ISF certified technician.

HDMI™, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing."

IMPORTANT INFORMATION TO PREVENT "IMAGE BURN / BURN-IN" ON YOUR TV SCREEN

- When a fixed image (e.g. logos, screen menus, video game, and computer display) is displayed on the TV for an extended period, it can become permanently imprinted on the screen. This phenomenon is known as "image burn" or "burn-in." Image burn is not covered under the manufacturer's warranty.
- In order to prevent image burn, avoid displaying a fixed image on your TV screen for a prolonged period (2 or more hours for LCD, 1 or more hours for Plasma).
- Image burn can also occur on the letterboxed areas of your TV if you use the 4:3 aspect ratio setting for an extended period.



PREPARATION

ACCESSORIES

Ensure that the following accessories are included with your TV. If an accessory is missing, please contact the dealer where you purchased the TV.

The accessories included may differ from the images below.



Owner's Manual



CD Manual



Remote Control, Batteries

Power Cord



Protection Cover (Refer to P.11)



Bolts for stand assembly (Refer to P.11)

Cable Holder



Polishing Cloth
(Not included with all models)

* Wipe spots on the exterior only with the polishing cloth.
* Do not wipe roughly when removing stain. Excessive pressure may cause scratch or discoloration.

Option Extras



D-sub 15 pin Cable

When using the VGA (D-sub 15 pin cable) PC connection, the user must use shielded signal interface cables with ferrite cores to maintain standards compliance.

FRONT PANEL INFORMATION

■ Image shown may differ from your TV.

⚠ CAUTION

G When the TV cannot be turned on with the remote control, press the main power button on the TV. (The remote control will not work when the main power on the TV is switched off.)

42/50PQ20



42/50PQ30, 42/50PS30



Remote Control Sensor
Intelligent Sensor
Adjusts picture according to the surrounding conditions.



Power/Standby Indicator
Illuminates red in standby mode.
Illuminates blue when the TV is switched on.



42/50PQ60, 50/60PS60





Remote Control Sensor
Intelligent Sensor
Adjusts picture according to the surrounding conditions.

Power/Standby Indicator
Illuminates red in standby mode.
Illuminates white when the TV is switched on and goes out slowly .



BACK PANEL INFORMATION

Only 42/50PQ60, 50/60PS60

- Image shown may differ from your TV.





1. HDMI/DVI IN, HDMI IN
   Digital Connection. Supports HD video and Digital audio. Doesn't support 480i.
   Accepts DVI video using an adapter or HDMI to DVI cable (not included)

2. OPTICAL DIGITAL AUDIO OUT
   Optical digital audio output for use with amps and home theater systems.
   Note: In standby mode, this port doesn't work.

3. RS-232C IN (CONTROL & SERVICE) PORT
   Used by third party devices.

4. AUDIO IN (RGB/DVI)
   1/8" headphone jack for analog PC audio input.
   RGB IN (PC)
   Analog PC Connection. Uses a D-sub 15 pin cable (VGA cable).

5. REMOTE CONTROL IN PORT
   For a wired remote control.

6. COMPONENT IN
   Analog Connection. Supports HD.
   Uses a red, green, and blue cable for video & red and white for audio.

7. AV (Audio/Video) IN
   Analog composite connection. Supports standard definition video only (480i).
   S-VIDEO
   Better quality than standard composition. Supports standard definition video only (480i).

8. ANTENNA/CABLE IN
   Connect over-the air signals to this jack.
   Connect cable signals to this jack.

9. USB IN
   Used for viewing photos and listening to MP3.

10. Power Cord Socket
    For operation with AC power.
    Caution: Never attempt to operate the TV on DC power.

STAND INSTRUCTION

- Image shown may differ from your TV.
- This part of STAND INSTRUCTION mainly use picture for 42PQ30/60 models.

Installation

1. Carefully place the TV screen side down on a cushioned surface to protect the screen from damage.



2. Assemble the TV as shown.



3. Fix the 4 bolts securely using the holes in the back of the TV.



NOTE



- When assembling the stand, make sure to distinguish and assemble the front and rear side of the stand correctly.
- When assembling the desk type stand, check whether the bolt is fully tightened. (If not tightened fully, the product can tilt forward after the product installation). If you tighten the bolt with excessive force, the bolt can deviate from abrasion of the tightening part of the bolt.

Detachment

1. Carefully place the TV screen side down on a cushioned surface to protect the screen from damage.



2. Loose the bolts from TV.



3. Detach the stand from TV.



Protection Cover

After removing the stand, install the included **protection cover** over the hole for the stand. Press the **PROTECTION COVER** into the TV until you hear it click.



DESKTOP PEDESTAL INSTALLATION

▪ Image shown may differ from your TV.

For proper ventilation, allow a clearance of 4 inches on all four sides from the wall.



⚠ CAUTION

- G Ensure adequate ventilation by following the clearance recommendations.
- G Do not mount near or above any type of heat source.

SWIVEL STAND

(This feature is not available for all models.)

After installing the TV, you can adjust the TV manually to the left or right direction by 20 degrees to suit your viewing position.



CABLE ARRANGEMENT

▪ Image shown may differ from your TV.

After connecting the cables as necessary, install **CABLE HOLDER** as shown and bundle the cables.



VESA WALL MOUNTING

Install your wall mount on a solid wall perpendicular to the floor. When attaching to other building materials, please contact your nearest installer.

If installed on a ceiling or slanted wall, it may fall and result in severe personal injury.

We recommend that you use an LG brand wall mount when mounting the TV to a wall.

LG recommends that wall mounting be performed by a qualified professional installer.

Model	VESA (A * B) 	Standard Screw	Quantity	Wall Mounting bracket (sold separately)
42PQ20, 42PQ30, 42PQ60, 50PQ20, 50PQ30, 50PQ60, 50PS30, 50PS60	400 * 400	M6	4	 AW-50PG60MS
60PS60	600 * 400	M8	4	 AW-60PG60MS

NOTE

- Screw length needed depends on the wall mount used. For further information, refer to the instructions included with the mount.
- Standard dimensions for wall mount kits are shown in the table.
- When purchasing our wall mount kit, a detailed installation manual and all parts necessary for assembly are provided.
- Do not use screws longer then the standard dimension, as they may cause damage to the inside to the TV.
- For wall mounts that do not comply with the VESA standard screw specifications, the length of the screws may differ depending on their specifications.
- Do not use screws that do not comply with the VESA standard screw specifications.
  Do not use fasten the screws too strongly, this may damage the TV or cause the TV to a fall, leading to personal injury. LG is not liable for these kinds of accidents.
- LG is not liable for TV damage or personal injury when a non-VESA or non specified wall mount is used or the consumer fails to follow the TV installation instructions.

CAUTION

- Do not install your wall mount kit while your TV is turned on. It may result in personal injury due to electric shock.

SECURING THE TV TO THE WALL TO PREVENT FALLING WHEN THE TV IS USED ON A STAND

- You should purchase necessary components to prevent the TV from tipping over (when not using a wall mount).
- Image shown may differ from your TV.

We recommend that you set up the TV close to a wall so it cannot fall over if pushed backwards.
Additionally, we recommend that the TV be attached to a wall so it cannot be pulled in a forward direction, potentially causing injury or damaging the product.
Caution: Please make sure that children don't climb on or hang from the TV.





- Insert the eye-bolts (or TV brackets and bolts) to tighten the product to the wall as shown in the picture.
  * If your product has the bolts in the eye-bolts position before inserting the eye-bolts, loosen the bolts.
  * Insert the eye-bolts or TV brackets/bolts and tighten them securely in the upper holes.
  Secure the wall brackets with the bolts (sold separately) to the wall. Match the height of the bracket that is mounted on the wall to the holes in the product.
  Ensure the eye-bolts or brackets are tightened securely.



- Use a sturdy rope (sold separately) to tie the product. It is safer to tie the rope so it becomes horizontal between the wall and the product.

NOTE

- Use a platform or cabinet strong enough and large enough to support the size and weight of the TV.
- To use the TV safely, make sure that the height of the bracket on the wall and the one on the TV are the same.

■ To prevent damage do not connect to the power outlet until all connections are made between the devices.

ANTENNA OR CABLE CONNECTION

1. Antenna (Analog or Digital)

Wall Antenna Socket or Outdoor Antenna without a Cable Box Connection.

For optimum picture quality, adjust antenna direction if needed.


Wall Antenna Socket
Multi-family Dwellings/Apartments
(Connect to wall antenna socket)
ANTENNA/ CABLE IN
Outdoor Antenna (VHF, UHF)
RF Coaxial Wire (75 ohm)
Single-family Dwellings /Houses
(Connect to wall jack for outdoor antenna)
Copper Wire
Be careful not to bend the copper wire when connecting the antenna.

2. Cable



■ To improve the picture quality in a poor signal area, please purchase a signal amplifier and install properly.
■ If the antenna needs to be split for two TV's, install a 2-Way Signal Splitter.
■ If the antenna is not installed properly, contact your dealer for assistance.

EXTERNAL EQUIPMENT SETUP

- To prevent the equipment damage, never plug in any power cords until you have finished connecting all equipment.
- Image shown may differ from your TV.

HD RECEIVER SETUP

This TV can receive Digital Over-the-air/Cable signals without an external digital set-top box. However, if you do receive digital signals from a digital set-top box or other digital external device, refer to the figure as shown below.

Component Connection

1. How to connect

1. Connect the video outputs (Y, PB, PR) of the digital set-top box to the **COMPONENT IN VIDEO 1** jacks on the TV. Match the jack colors (Y = green, PB = blue, and PR = red).
2. Connect the audio output of the digital set-top box to the **COMPONENT IN AUDIO 1** jacks on the TV.



2. How to use

- Turn on the digital set-top box.
  (Refer to the owner's manual for the digital set-top box. operation)
- Select the **Component1** input source on the TV using the **INPUT** button on the remote control.
- If connected to **COMPONENT IN 2** input, select the **Component2** input source on the TV.

Supported Resolutions

Signal	Component	HDMI
480i	Yes	No
480p	Yes	Yes
720p	Yes	Yes
1080i	Yes	Yes
1080p	Yes	Yes

Y, CB/PB, CR/PR

Resolution	Horizontal Frequency(KHz)	Vertical Frequency(Hz)
720x480i	15.73 15.73	59.94 60.00
720x480p	31.47 31.50	59.94 60.00
1280x720p	44.96 45.00	59.94 60.00
1920x1080i	33.72 33.75	59.94 60.00
1920x1080p	27.00 33.75 67.43 67.50	24.00 30.00 59.94 60.00

HDMI Connection

1. How to connect

1. Connect the digital set-top box to **HDMI/DVI IN 1**, **2**, **3** or **4** (Only 42/50PQ60, 50/60PS60) jack on the TV.

2. No separate audio connection is necessary.
   HDMI supports both audio and video.

2. How to use

- Turn on the digital set-top box.
  (Refer to the owner's manual for the digital set-top box.)
- Select the **HDMI1**, **2**, **3** or **4** (Only 42/50PQ60, 50/60PS60) input source on the TV using the **INPUT** button on the remote control.



NOTE

- Check HDMI cable over version 1.3.
  If the HDMI cables don't support HDMI version 1.3, it can cause flickers or no screen display. In this case use the latest cables that support HDMI version 1.3.

HDMI-DTV

Resolution	Horizontal Frequency(KHz)	Vertical Frequency(Hz)
720x480p	31.469 31.50	59.94 60.00
1280x720p	44.96 45.00	59.94 60.00
1920x1080i	33.72 33.75	59.94 60.00
1920x1080p	27.00 33.75 67.43 67.50	24.00 30.00 59.94 60.00

DVI to HDMI Connection

1. How to connect

1. Connect the DVI output of the digital set-top box to the **HDMI/DVI IN 1**, **2**, **3** or **4** (Only 42/50PQ60, 50/60PS60) jack on the TV.
2. Connect the audio output of the digital set-top box to the **AUDIO IN (RGB/DVI)** jack on the TV.



2. How to use

- Turn on the digital set-top box. (Refer to the owner's manual for the digital set-top box.)
- Select the **HDMI1**, **2**, **3** or **4** (Only 42/50PQ60, 50/60PS60) input source on the TV using the **INPUT** button on the remote control.

NOTE

G A DVI to HDMI cable or adapter is required for this connection. DVI doesn't support audio, so a separate audio connection is necessary.

DVD SETUP

Component Connection

1. How to connect

1. Connect the video outputs (Y, P_B, P_R) of the DVD to the **COMPONENT IN VIDEO 1** jacks on the TV.
   Match the jack colors (Y = green, P_B = blue, and P_R = red).

2. Connect the audio outputs of the DVD to the **COMPONENT IN AUDIO 1** jacks on the TV.



2. How to use

- Turn on the DVD player, insert a DVD.
- Select the **Component1** input source on the TV using the **INPUT** button on the remote control.
- If connected to **COMPONENT IN 2** input, select the **Component2** input source on the TV.
- Refer to the DVD player's manual for operating instructions.

Component Input ports

To get better picture quality, connect a DVD player to the component input ports as shown below.

Component ports on the TV	Y	P_B	P_R
Video output ports on DVD player	Y	P_B	P_R
	Y	B-Y	R-Y
	Y	Cb	Cr
	Y	Pb	Pr

S-Video Connection

1. How to connect

1. Connect the S-VIDEO output of the DVD to the **S-VIDEO** input on the TV.
2. Connect the audio outputs of the DVD to the **AUDIO** input jacks on the TV.



2. How to use

- Turn on the DVD player, insert a DVD.
- Select the **AV1** input source on the TV using the **INPUT** button on the remote control.
- Refer to the DVD player's manual for operating instructions.

HDMI Connection

1. How to connect

1. Connect the HDMI output of the DVD to the **HDMI/DVI IN 1**, **2**, **3** or **4** (Only 42/50PQ60, 50/60PS60) jack on the TV.
2. No separate audio connection is necessary.
   HDMI supports both audio and video.



2. How to use

- Select the **HDMI1**, **2**, **3** or **4** (Only 42/50PQ60, 50/60PS60) input source on the TV using the **INPUT** button on the remote control.
- Refer to the DVD player's manual for operating instructions.

VCR SETUP

Antenna Connection

1. How to connect

1. Connect the RF antenna out socket of the VCR to the **ANTENNA/CABLE IN** socket on the TV.
2. Connect the antenna cable to the RF antenna in socket of the VCR.



2. How to use

- Set VCR output switch to 3 or 4 and then tune TV to the same channel number.
- Insert a video tape into the VCR and press PLAY on the VCR. (Refer to the VCR owner's manual.)

Composite (RCA) Connection

1. How to connect

1 Connect the **AUDIO/VIDEO** jacks between TV and VCR. Match the jack colors (Video = yellow, Audio Left = white, and Audio Right = red)



2. How to use

- Insert a video tape into the VCR and press PLAY on the VCR. (Refer to the VCR owner's manual.)
- Select the **AV1** input source on the TV using the **INPUT** button on the remote control.
- If connected to **AV IN 2**, select **AV2** input source on the TV.

NOTE

G If you have a mono VCR, connect the audio cable from the VCR to the **AUDIO L/MONO** jack of the TV.

S-Video Connection

1. How to connect

1 Connect the S-VIDEO output of the VCR to the **S-VIDEO** input on the TV.

2 Connect the audio outputs of the VCR to the **AUDIO** input jacks on the TV.



2. How to use

- Insert a video tape into the VCR and press PLAY on the VCR. (Refer to the VCR owner's manual.)
- Select the **AV1** input source on the TV using the **INPUT** button on the remote control.

NOTE

G S-Video provides better quality than composite. Use it when available.

CAUTION

G Do not connect to both Video and S-Video at the same time. In the event that you connect both Video and the S-Video cables, only the S-Video will work.

OTHER A/V SOURCE SETUP

1. How to connect

1. Connect the **AUDIO/VIDEO** jacks between TV and external equipment. Match the jack colors.
   (Video = yellow, Audio Left = white, and Audio Right = red)

2. How to use

- Select the **AV2** input source on the TV using the **INPUT** button on the remote control.
- If connected to **AV IN 1** input, select the **AV1** input source on the TV.
- Operate the corresponding external equipment.



AUDIO OUT CONNECTION

Send the TV's audio to external audio equipment via the Audio Output port.

1. How to connect

1. Connect one end of the optical cable to the TV's **OPTICAL** port of **DIGITAL AUDIO OUT**.
2. Connect the other end of the optical cable to the digital audio input on the audio equipment.
3. Set the "TV Speaker option - Off" in the AUDIO menu. (G **p.76**). See the external audio equipment instruction manual for operation.



NOTE

G When connecting with external audio equipment, such as amplifiers or speakers, you can turn the TV speakers off in the menu. (G **p.76**)

CAUTION

G Do not look into the optical output port. Looking at the laser beam may damage your vision.
G Audio with ACP (Audio Copy Protection) function may block digital audio output.

USB CONNECTION

i.e)



1. How to connect

1 Connect the USB device to the **USB IN** jack on the side of TV.

2. How to use

■ After connecting the **USB IN** jack, you use the USB function. (G p.50)

PC SETUP

This TV provides Plug and Play capability, meaning that the PC adjusts automatically to the TV's settings.

VGA (D-Sub 15 pin) Connection

1. How to connect

1. Connect the VGA output of the PC to the **RGB IN (PC)** jack on the TV.
2. Connect the PC audio output to the **AUDIO IN (RGB/DVI)** jack on the TV.



2. How to use

- Turn on the PC and the TV.
- Select the **RGB-PC** input source on the TV using the **INPUT** button on the remote control.

DVI to HDMI Connection

1. How to connect

1. Connect the DVI output of the PC to the **HDMI/DVI IN 1**, **2**, **3** or **4** (Only 42/50PQ60, 50/60PS60) jack on the TV.
2. Connect the PC audio output to the **AUDIO IN (RGB/DVI)** jack on the TV.



2. How to use

- Turn on the PC and the TV.
- Select the **HDMI1**, **2**, **3** or **4** (Only 42/50PQ60, 50/60PS60) input source on the TV using the **INPUT** button on the remote control.

Supported Display Specifications (RGB-PC, HDMI-PC)

Resolution	Horizontal Frequency(KHz)	Vertical Frequency(Hz)
720x400	31.468	70.08
640x480	31.469	59.94
800x600	37.879	60.31
1024x768	48.363	60.00
1280x768	47.78	59.87
1360x768	47.72	59.80
1920x1080	66.647	59.988

NOTES

- 42/50PQ20, 42/50PQ30, 42/50PQ60: To get the the best picture quality, adjust the PC graphics card to 1360x768.
- 50PS30, 50/60PS60: To get the the best picture quality, adjust the PC graphics card to 1920x1080.
- Depending on the graphics card, DOS mode may not work if a HDMI to DVI Cable is in use.
- In PC mode, there may be noise associated with the resolution, vertical pattern, contrast or brightness. If noise is present, change the PC output to another resolution, change the refresh rate to another rate or adjust the brightness and contrast on the PICTURE menu until the picture is clear.
- Avoid keeping a fixed image on the screen for a long period of time. The fixed image could become permanently imprinted on the screen.
- The synchronization input form for Horizontal and Vertical frequencies is separate.
- Depending on the graphics card, some resolution settings may not allow the image to be positioned on the screen properly.

Screen Setup for PC mode

Selecting Resolution

You can choose the resolution in RGB-PC mode.
The **Position**, **Phase**, and **Size** can also be adjusted.





1 MENU — Select **PICTURE**.

2 ENTER — Select **Screen (RGB-PC)**.

3 ENTER — Select **Resolution**.

4 ENTER — Select the desired resolution.

5 ENTER

Auto Configure

Automatically adjusts picture position and minimizes image instability. After adjustment, if the image is still not correct, try using the manual settings or a different resolution or refresh rate on the PC.



1 MENU — Select **PICTURE**.

2 ENTER — Select **Screen (RGB-PC)**.

3 ENTER — Select **Auto config.**.

4 ENTER — Select **Yes**.

5 ENTER — Start Auto Configuration.

- If the position of the image is still not correct, try Auto adjustment again.
- If picture needs to be adjusted again after Auto adjustment in RGB-PC, you can adjust the **Position**, **Size** or **Phase**.

Adjustment for screen Position, Size, and Phase

If the picture is not clear after auto adjustment and especially if characters are still trembling, adjust the picture phase manually.

This feature operates only in RGB-PC mode.

1 MENU — Select **PICTURE**.

2 ENTER — Select **Screen (RGB-PC)**.

3 ENTER — Select **Position**, **Size**, or **Phase**.

4 ENTER — Make appropriate adjustments.

5 ENTER

- **Position**: This function is to adjust picture to left/right and up/down as you prefer.
- **Size**: This function is to minimize any vertical bars or stripes visible on the screen background. And the horizontal screen size will also change.
- **Phase**: This function allows you to remove any horizontal noise and clear or sharpen the image of characters.

Screen Reset (Reset to original factory values)

Returns **Position**, **Size**, and **Phase** to the default factory settings.
This feature operates only in RGB-PC mode.

1 MENU — Select **PICTURE**.

2 ENTER — Select **Screen (RGB-PC)**.

3 ENTER — Select **Reset**.

4 ENTER — Select **Yes**.

5 ENTER

WATCHING TV / CHANNEL CONTROL

REMOTE CONTROL FUNCTIONS

When using the remote control, aim it at the remote control sensor on the TV.

42/50PQ60, 50PS30, 50/60PS60

TV/STB/DVD Select the remote operating mode: TV, STB or DVD.

POWER Turns the TV on from standby or off to standby.

ENERGY SAVING Adjusts the Energy Saving.

Q.MENU Opens the list of Quick Menu options. G p.38

MENU Displays the main menu or clears all on-screen displays and returns to TV viewing.

INPUT Rotates through inputs.
Also switches the TV on from standby. G p.45

NUMBER button

— (DASH) Used to enter a program number for multiple program channels such as 2-1, 2-2, etc.

LIST Displays the channel list.

FLASHBK Tunes to the last channel viewed.

VCR, USB, SIMPLINK Control buttons
- Controls USB menu (PHOTO LIST and MUSIC LIST).
- Controls the SIMPLINK compatible devices.

SIMPLINK See a list of AV devices connected to TV.
When you toggle this button, the SIMPLINK menu appears at the screen. G p.48-49

RATIO Changes the aspect ratio of the video. G p.58

FREEZE Freezes the current frame.

THUMBSTICK (Up/Down/Left Right/ENTER)	Navigates the on-screen menus and adjusts the system settings to your preference.
RETURN	Allows the user to move return one step in an interactive application or other user interaction function.
INFO	Displays channel information at the top of the screen.
AV MODE	Toggles through preset Video and Audio modes. G p.47

VOLUME UP /DOWN	Adjusts the volume.
FAV	Scroll through the programmed Favorite channels. G p.43
MARK	Use to mark or unmark a photo/music G p.52
MUTE	Switches the sound on or off. G p.34
CHANNEL UP/DOWN	Changes the channel.
PAGE UP/DOWN	Moves from one full set of screen information to the next one.

Installing Batteries



- Open the battery compartment cover on the back side and install the batteries matching correct polarity.
- Install two 1.5V AAA batteries. Don't mix old or used batteries with new ones.
- Close cover.

42/50PQ20, 42/50PQ30

INFO Displays channel information at the top of the screen.

AV MODE Toggles through preset Video and Audio modes. G p.47

POWER Turns the TV on from standby or off to standby.

INPUT Rotates through inputs.
Also switches the TV on from standby. G p.45

ENERGY SAVING Adjusts the Energy Saving.

VOLUME UP /DOWN Adjusts the volume.

MUTE Switch the sound on or off. G p.34

CHANNEL UP/DOWN Changes the channel.

PAGE UP/DOWN Moves from one full set of screen information to the next one.

VCR, USB, SIMPLINK Control buttons
- Controls USB menu (PHOTO LIST and MUSIC LIST).
- Controls the SIMPLINK compatible devices.

Q.MENU Opens the list of Quick Menu options. G p.38

SIMPLINK See a list of AV devices connected to TV.
When you toggle this button, the SIMPLINK menu appears at the screen. G p.48-49

FREEZE Freezes the current frame.

RATIO Changes the aspect ratio of the video. G p.58

FAV Scroll through the programmed Favorite channels. G p.43

MARK Use to mark or unmark a photo/music G p.52



NUMBER button

— (DASH) Used to enter a program number for multiple program channels such as 2-1, 2-2, etc.

LIST Displays the channel list.

FLASHBK Tunes to the last channel viewed.

THUMBSTICK (Up/Down/Left Right/ENTER) Navigates the on-screen menus and adjusts the system settings to your preference.

MENU Displays the main menu or clears all on-screen displays and returns to TV viewing.

RETURN Allows the user to move return one step in an interactive application or other user interaction function.

Installing Batteries



- Open the battery compartment cover on the back and install the batteries matching correct polarity.
- Install two 1.5V AAA batteries. Do not mix old or used batteries with new ones.
- Close cover.

TURNING ON TV

Turning on TV just after installation

1. First, connect power cord correctly.
   At this moment, TV is in standby mode.
   ■ In standby mode to turn TV on, press the **INPUT**, **CH (D or E)** button on the TV or press the **POWER**, **INPUT**, **CH(∧ or ∨)**, **Number (0~9)** button on the remote control.

2. Select the viewing source by using the **INPUT** button on the remote control.
   ■ This TV is programmed to remember which power state it was last set to, even if the power cord is out.

Turning on TV in use (power cord is still connected)

Case 1) Press the **POWER** button on the remote control. The TV reverts to standby mode.
- To turn TV on, press the **INPUT**, **CH (D or E)** button on the TV or press the **POWER**, **INPUT**, **CH(∧ or ∨)**, **Number (0~9)** button on the remote control.
  You can press the main power to shutdown the TV from standby mode to use even less power that standby mode.

Case 2) Main power(⏻/I) on the TV is switched off.
- To turn TV on, you must press the main power (⏻/I) button on the TV.

Case 3) Press the **POWER** button on the remote control and then main power(⏻/I) on the TV is switched off.
- To turn TV on, you must press the main power (⏻/I) button on the TV.

NOTE
- If you intend to be away on vacation, disconnect the power plug from the wall power outlet.
- If you unplug the TV once or turn the main power off, the clock function reset.

CHANNEL SELECTION

1. Press the **CH (∧ or ∨)** or **NUMBER** buttons to select a channel number.

VOLUME ADJUSTMENT

Adjust the volume to suit your personal preference.

1. Press the **VOL (+ or -)** button to adjust the volume.
2. If you want to switch the sound off, press the **MUTE** button.
3. You can cancel the Mute function by pressing the **MUTE** or **VOL (+ or -)** button.

INITIAL SETTING

This Function guides the user to easily set the essential items for viewing the TV for the first time when purchasing the TV. It will be displayed on the screen when turning the TV on for the first time. It can also be activated from the user menus.

- Default selection is "**Home Use**". We recommend setting the TV to "**Home Use**" mode for the best picture in your home environment.
- "**Store Demo**" Mode is only intended for use in retail environments. Customers can adjust the "**Picture** menu - **Picture mode**" manually while inspecting the TV, but the TV will automatically return to preset in-store mode after 5 minutes.
- You can also adjust **Initial Setting** in the **OPTION** menu.

  Factory defaults are set when you choose "**Home Use**".
- If you do not complete the **Initial setting**, it will appear whenever the TV is switched on until the **Initial setting** procedure is completed.

Step1. Language Selecting





Select menu Language.

Step2. Mode setting





Select **Home Use** mode.

Step3. Time setting

1 Select **Auto** or **Manual**.

2 Select desired time option.

Step4. Auto Tuning



1 Start **Auto Tuning**.

ON-SCREEN MENUS SELECTION

Your TV's OSD (On Screen Display) may differ slightly from that shown in this manual.



For USA For Canada

1 MENU Display each menu.

2 ENTER Select a menu item.

3 ENTER Accept the current selection.

4 MENU Return to TV viewing.

QUICK MENU

Your TV's OSD (On Screen Display) may differ slightly from what is shown in this manual.
Q.Menu (Quick Menu) is a menu of features which users might use frequently.

- **Aspect Ratio**: Selects your desired picture format.
- **Picture Mode**: Selects the factory preset picture depend on the viewing environment.
- **Sound Mode**: Selects the factory preset sound for type of program.
- **Caption**: Select on or off.
- **Multi Audio**: Changes the audio language (Digital signal).
  SAP: Selects MTS sound (Analog signal).
- **Sleep Timer**: Select the amount of time before your TV turns off automatically.
- **Del/Add/Fav**: Select channel you want to add/delete or add the channel to the Favorite List.
- **Eject USB**: Select “Eject” in order to eject a USB device.



1 Q. MENU — Display each menu.

2 — Make appropriate adjustments.

3 Q. MENU — Return to TV viewing.

CHANNEL SETUP

Auto Scan (Auto Tuning)

Automatically finds all channels available through antenna or cable inputs, and stores them in memory on the channel list.



1 MENU Select **CHANNEL**.

2 ENTER Select **Auto Tuning**.

3 ENTER Select **Yes**.

4 ENTER Run **Auto Tuning**.

5 RETURN Return to the previous menu.

MENU Return to TV viewing.

- The TV will ask for a password if parental control has been activated (Lock Menu). Use the password you set up in the Lock Menu to allow a channel search.

Add/Delete Channel (Manual Tuning)

If you select DTV or CADTV input signal, you can view the on-screen signal strength monitor to see the quality of the signal being received.



1 MENU — Select **CHANNEL**.

2 ENTER — Select **Manual Tuning**.

3 ENTER — Select **DTV**, **TV**, **CADTV**, or **CATV**.

4 — Select channel you want to add or delete.

5 ENTER — Select **Add** or **Delete**.

6 RETURN — Return to the previous menu.

MENU — Return to TV viewing.

■ The TV will ask for a password if parental control has been activated (Lock Menu). Use the password you set up in the Lock Menu to allow a channel search.

Channel Editing

When a channel number is deleted, it means that you will be unable to select it using CH ∧, ∨ button during TV viewing.

If you wish to select the deleted channel, directly enter the channel number with the NUMBER buttons or select it in the Channel Edit menu.



1 MENU Select **CHANNEL**.

2 ENTER Select **Channel Edit**.

3 ENTER Select a channel.

4 Add or delete the channel.

5 RETURN Return to the previous menu.

MENU Return to TV viewing.

CHANNEL LIST

You can check channels which are stored in the memory by displaying the channel list.

This padlock is displayed when the channel is locked with parental control



Displaying Channel List

1 LIST

Display the **Channel List**.

Selecting a channel in the channel list

1

Select a channel.

2 ENTER

Switch to the chosen channel number.

Paging through a channel list

1 CH PAGE

Turn the pages.

2 RETURN

Return to TV viewing.

FAVORITE CHANNEL SETUP

Your TV's OSD (On Screen Display) may differ slightly from what is shown in this manual.

Favorite Channels are a convenient feature that lets you quickly select channels of your choice without waiting for the TV to select through all the in-between channels.
To tune to a favorite channel, press the **FAV** (Favorite) button repeatedly.



1 CH PAGE or 0–9 Select your desired channel.

2 Q. MENU Select **Del/Add/Fav**.

3 Select **Favorite**.

4 Q. MENU Return to TV viewing.

FAVORITE CHANNEL LIST



Displaying the favorite channel list

1 MARK FAV or FAV MARK Display the Favorite channel list.

Selecting a channel in the favorite channel list

1 Select a channel.

2 ENTER Switch to the chosen channel number.

Paging through a favorite channel list

1 CH PAGE Turn the pages.

2 RETURN Return to TV viewing.

BRIEF INFORMATION

Brief Info shows the present screen information.

1 INFO or ENTER Show the Brief Info on the screen.

2 RETURN Return to TV viewing



	Multilingual : The program contains two or more audio services. Use the **Q.MENU** menu to select wanted Audio.
CC	**Caption** : The program contains one or more caption services. Use the **Q.MENU** menu to select wanted Closed caption.
4:3	The original aspect ratio of the video is 4:3
16:9	The original aspect ratio of the video is 16:9 (wide)
480i	The video resolution is 720x480i
480p	The video resolution is 720x480p
720p	The video resolution is 1280x720p
1080i	The video resolution is 1920x1080i
1080p	The video resolution is 1920x1080p
	V-Chip: The program contains V-Chip information. Refer to the LOCK menu: A (Age), D (Dialogue), L (Language), S (Sex), V (Violence), FV (Fantasy Violence)

1. Program title
2. Day, Month, Year
3. Program start time
4. Program progress bar
5. Program finish time
6. Present time
7. Banner information

INPUT LIST

Only these input signals which are connected to a TV can be activated and selected.

1 

Select the desired input source.



ie)



Disconnected inputs are inactive (grayed out)

Select a desired input source (except **TV**). Then, you can select your desired **Input Label** with using Blue button. G **p.46**

ie) In case of changing the input label with using Blue button

- When new external device is connected, this popup menu is displayed automatically.
  If selecting **Yes**, you can select input source that you want to appreciate.
- But, when selecting "**SIMPLINK - On**", popup menu for HDMI input will not be displayed.



- **TV**: Select it to watch over-the-air, cable and digital cable broadcasts.
- **AV 1-2**: Select them to watch a VCR or other external equipment.
- **Component 1-2**: Select them to watch DVD or a Digital set-top box.
- **RGB-PC**: Select it to view PC input.
- **HDMI1-3** or **1-4**: Select them to watch high definition devices.

INPUT LABEL

You can set a label for each input source when it's not in use.



With using OPTION menu

1 MENU — Select **OPTION**.

2 ENTER — Select **Input Label**.

3 ENTER — Select the source.

4 Select the label.

5 RETURN — Return to the previous menu.

MENU — Return to TV viewing.

With using INPUT button

1 INPUT or INPUT — Select the source(except **TV**).

2 Select the label.

3 RETURN — Return to the previous menu.

MENU — Return to TV viewing.

AV MODE

AV Mode toggles through preset Video and Audio settings.



1 Press the **AV MODE** button repeatedly to select the desired source.

2

- If you select "**Cinema / THX Cinema**" in AV mode, **Cinema** will be selected both for "PICTURE menu - Picture Mode" and "AUDIO menu - Sound Mode" respectively.
- If you select "**Off**" in AV mode, the "**Picture Mode**" and "**Sound Mode**" return to previous selected value.
- **Off**: Disables the AV MODE.
- **Cinema**: Optimizes video and audio for watching movies.
- **Sport**: Optimizes video and audio for watching sports events.
- **Game**: Optimizes video and audio for playing games.

Simplink allows you to control and play other AV devices connected with HDMI cable without additional cables and settings. This TV may work with devices with HDMI-CEC support, but only devices with the SIMPLINK logo are fully supported.

SIMPLINK can be turned on and off in the user menus.



1 MENU Select **OPTION**.

2 ENTER Select **SIMPLINK**.

3 ENTER Select **On** or **Off**.

4 RETURN Return to the previous menu.

MENU Return to TV viewing.

NOTE

- Connect the HDMI/DVI IN or HDMI IN terminal of the TV to the rear terminal (HDMI terminal) of the SIMPLINK device with the HDMI cable.
- When you switch the Input source with the INPUT button on the remote control, the SIMPLINK device will stop.
- When you select a device with home theater functionality, the sound output automatically switches to the home theater speakers and the TV speakers are turned off.
- If a connected SIMPLINK home theater system doesn't play the audio from the TV, connect the DIGITAL AUDIO OUT terminal on the back of the TV to the DIGITAL AUDIO IN terminal on the back of the SIMPLINK device with an OPTICAL cable.

SIMPLINK Functions

- **Direct Play:** After connecting AV devices to the TV, you can directly control the devices and play media without additional settings.
- **Select AV device:** Enables you to select one of the AV devices connected to TV.
- **Disc playback:** Control connected AV devices by pressing the ▲ ▼ ◀ ▶, ENTER, G, A, II, F F and G G buttons.
- **Power off all devices:** When you power off the TV, all connected devices are turned off.
- **Switch audio-out:** Offers an easy way to switch audio-out.
- **Sync Power on:** When the equipment with Simplink function connected HDMI terminal starts to play, The TV will change automatically to turn on mode.

(A device, which is connected to the TV through a HDMI cable but does not support SIMPLINK, does not provide this function)

Note: To operate SIMPLINK, an HDMI cable over Version 1.3 with *CEC function should be used. (*CEC: Consumer Electronics Control).

1 Display **SIMPLINK** menu.

2 Select the desired device.

3 Control connected AV devices.



SIMPLINK Menu

1. **TV viewing**: Switch to the previous TV channel regardless of the current mode.
2. **DISC playback**: Select and play discs. When multiple discs are available, the titles of discs are conveniently displayed at the bottom of the screen.
3. **VCR playback**: Control the connected VCR.
4. **HDD Recordings playback**: Control recordings stored in HDD.
5. **Audio Out to Home Theater speaker/Audio Out to TV**: Select Home Theater speaker or TV speaker for Audio Out.

G When no device is connected (displayed in gray)
G Selected Device

G When a device is connected (displayed in bright color)

USB

ENTRY MODES

When you connect a USB device, this screen is displayed automatically.
In USB device, you can not add a new folder or delete the existing folder.

1 Connect the USB device to the **USB IN** jacks on the side of TV.

- It doesn't support USB HDD.
- This TV supports JPG and MP3 files.



2 Select **Photo List** or **Music List**.



3 ENTER

NOTE

G In order to avoid losing the USB memory stick, use the USB connector to fix the USB memory stick to the USB connector holder of the TV.


USB connector holder
USB Input Port
USB Connector (sold separately)
- Fix the one end of the USB connector to the USB memory stick and the other end to the USB connector holder.

When removing the USB device

Select the **Eject USB** menu before removing the USB device.

1 Q. MENU — Select **Eject USB**.

2 ENTER — Select **Eject**.

Precautions when using the USB device

- G Only a USB storage device is recognizable.
- G If the USB storage device is connected through a USB hub, the device is not recognizable.
- G A USB storage device using an automatic recognition program may not be recognized.
- G A USB storage device which uses its own driver may not be recognized.
- G In case of a card reader, up to four memory cards are concurrently recognizable.
- G The recognition speed of a USB storage device may depend on each device.
- G Please do not turn off the TV or unplug the USB device when the connected USB storage device is working. When such device is suddenly separated or unplugged, the stored files or the USB storage device may be damaged.
- G Only use a USB storage device which has normal music files or image files.
- G Please use only a USB storage device which was formatted as a FAT16, FAT32 or NTFS file system provided with the Windows operating system. In case of a storage device formatted as a different utility program which is not supported by Windows, it may not be recognized.
- G Please connect power to a USB storage device which requires an external power supply. If not, the device may not be recognized.
- G Please connect a USB storage device with cable is offered by USB maker. If connected with cable is not offered by USB maker or an excessively long cable, the device may not be recognized.
- G Some USB storage devices may not be supported or operate properly.
- G The TV will display up to 128 characters of a files name.
- G Please backup important files because data on USB device may be damaged. Data management is consumer's responsibility and as a result, the manufacturer does not cover data damage.

PHOTO LIST

You can view .JPG files from USB storage devices.
The On Screen Display on your model may be slightly different.

Supported photo file: *.JPG

- You can play JPG files only.
- Only baseline scan is supported among JPG.

Screen Components



1. Moves to upper level file
2. Preview: Display the thumbnail/folder name of the photo in the selected folder
3. Current page/Total pages
4. Total number of marked photos
5. Usable USB memory
6. Corresponding buttons on the remote control

Photo Selection and Popup Menu



When you select a file (not folder), this PopUp menu is displayed.

- **View**: Display the selected item.
- **Mark All**: Mark all photos on the screen.
- **Unmark All**: Deselect all marked photos.
- **Delete**: Delete the selected photo item.
- **Close**: Close the pop-up menu.

1 Select the target folder or drive.

2 Select the desired photos.

3 Show the Popup menu.

4 Select the desired Popup menu.

- Use the **CH** ∧ ∨ button to navigation in the photo page.
- Use the **MARK** button to mark or unmark a photo. When one or more photos are marked, you can view individual photos or a slide show of the marked photos. If no photos are marked, you can view all photos individually or all photos in the folder in a slide show.

Full Screen Menu

You can change the Photo List view so that it fills the screen. More operations are available in full screen mode.





The aspect ratio of a photo may change the size of the photo displayed on the screen in full size.

1 Select the target folder or drive.

2 Select the desired photos.

3 Show the Popup menu.

4 Select **View**.

5 The selected photo is displayed in full size.

■ Use the **CH** ∧ ∨ button to navigation in the photo page.

6 

Select the **Slideshow**, **BGM**, **(Rotate)**, **Delete**, **Option**, or **Hide**.

- Use < > button to select the previous or next photo.
- Use ∧ ∨ < > button to select and control the menu on the full-sized screen.

- **Slideshow**: Selected photos are displayed during the slide show. If no photo is selected, all photos in the current folder are displayed during slide show.
  - Set the time interval of the slide show in **Option**.
- **BGM**: Listen to music while viewing photos in full size.
  - Set the BGM device and album in **Option**.
- **(Rotate)**: Rotate photos.
  - Rotates the photo 90°, 180°, 270°, 360° clockwise.
- **Delete**: Delete photos.
- **Option**: Set values for **Slide Speed** and **Music Folder**.
  - Use < > button and **ENTER** button to set values. Then go to Enter and press **ENTER** to save the settings.
  - You cannot change **Music Folder** while BGM is playing.
- **Hide** : Hide the menu on the full-sized screen.
  - To see the menu again on the full-sized screen, press **ENTER** button to display.



NOTE

- This TV will not be able to decode most JPEG images saved using the Progressive option.

MUSIC LIST

You can use the Music List menu to play MP3 files form a USB storage device.
This TV cannot play back copy-protected files.
The On Screen Display on your model may be slightly different.

Supported music file: *.MP3
Bit rate range 8Kbps ~ 320Kbps
- Sampling rate (Sampling Frequency)
  MPEG1Layer 3 : 8KHz ~ 48KHz
- Music Max Length : 999.59 Sec.

Screen Components



1. Moves to upper level file
2. Preview: Display the title/folder name of the music in the selected folder
3. Current page/Total pages
4. Total number of marked musics
5. Usable USB memory
6. Corresponding buttons on the remote control

Music Selection and Popup Menu

Up to 6 music titles are listed per page.



- **Play** (During stop): Play the selected music. Once a song finishes playing, the next selected one will be played. When there are no selected musics to play, the next one in the current folder will be played. If you go to a different folder and press the **ENTER** button, the current music in playback will stop.
- **Play Marked**: Play the selected musics. Once a music finishes playing, the next selected one will be played automatically.
- **Stop Play** (During playback): Stop the playing musics.
- **Play with Photo**: Start playing the selected musics and then move to the Photo List.
- **Mark All**: Mark all musics in the folder.
- **Unmark All**: Deselect all marked music.
- **Delete**: Delete the selected music.
- **Close**: Close the pop-up menu.

1 Select the target folder or drive.

2 Select the desired musics.

3 Show the Popup menu.

4 Select the desired Popup menu.

5 Return to TV viewing

- Use the **CH** ∧ ∨ button to navigation in the music page.
- Use **MARK** button to mark or unmark a music file. If no music is marked, all the music in the folder will be played in sequence. When one or more music files are marked, the marked music files will be played in sequence. If you want to listen to only one song repeatedly, just mark that one file and play.

■ The play information box (as shown below) will automatically move across the screen when there is no user input to prevent a fixed image remaining on the screen for a extended period of time.

NOTE

- When music is playing, is displayed in front of the music play time.
- A damaged or corrupted music file that does not play displays 00:00 as the play time.
- Music files with copy-protection will not play.
- Press **ENTER**, **A** , or **RETURN** button to stop the screen saver.
- This TV can not play music files less than 16 Kbytes.

PICTURE CONTROL

PICTURE SIZE (ASPECT RATIO) CONTROL

This feature lets you choose the way an analog picture with a 4:3 aspect ratio is displayed on your TV.

■ RGB-PC input source use 4:3 or 16:9 aspect ratio.





1 Q. MENU Select the **Aspect Ratio**.

2 Select the desired picture format.

3 Q. MENU Return to TV viewing.

■ You can also press the **RATIO** botton repeatedly on the remote control.

16:9

Adjust the picture horizontally, in a linear proportion to fill the entire screen.

Just Scan

Normally the edges of video signals are cropped 1-2%. Just Scan turns off this cropping and shows the complete video.

Notes: If there is noise on the edges of the original signal, it will be visible when Just Scan is activated.

Just Scan operates only in DTV/CADTV/Component/HDMI-DTV/DVI-DTV (720p/1080i/1080p) input source.

Set by program

Selects the proper picture proportion to match the source's image.

(4:3➞ 4:3)

(16:9➞ 16:9)

4:3

Choose 4:3 when you want to view a picture with an original 4:3 aspect ratio.



Zoom

Choose Zoom when you want to view the picture without any alteration. However, the top and bottom portions of the picture will be cropped.



Cinema Zoom

Choose Cinema Zoom when you want to enlarge the picture in correct proportion. Note: When enlarging or reducing the picture, the image may become distorted.

- The adjustment range is 1-16.

ENERGY SAVING

It reduces the TV's power consumption.

The default factory setting complies with the **Energy Star** requirements and is adjusted to the comfortable level to be viewed at home.

You can increase the brightness of your screen by adjusting the Energy Saving level or by setting the **Picture Mode**.

This feature is disabled in "**Picture Mode-Cinema**".



1 MENU Select **PICTURE**.

2 ENTER Select **Energy Saving**.

3 ENTER Select **Intelligent Sensor** ( ) Select **Low**, **Middle**, or **High**.), **Off**, **Minimum**, **Medium** or **Maximum**.

4 RETURN Return to the previous menu.

MENU Return to TV viewing.

- You can also adjust the **ENERGY SAVING** button on the remote control.
- **Intelligent Sensor?**

  This function automatically adjusts the brightness of screen to the most suitable picture according to the surrounding conditions.

PRESET PICTURE SETTINGS (PICTURE MODE)

There are factory presets for picture settings available in the user menus. You can use a preset, change each setting manually.





1 Q. MENU

Select **Picture Mode**.

2

Select **Vivid**, **Standard**, **Cinema (or THX Cinema)**, **Sport**, **Game**, **Expert1** or **Expert2**.

3 Q. MENU

Return to TV viewing.

- **Vivid**, **Standard**, **Cinema(or THX Cinema)**, **Sport**, and **Game** Settings are preset for the optimum picture quality at the factory.
- You can also adjust **Picture Mode** in the **PICTURE** menu.
- **Vivid**: This is the mode to maximize the effect of the video in the retail store. Strengthen the contrast, brightness, color and sharpness for vivid picture.
- **Standard**: This is the mode to realize optimum viewing condition for the general user.
- **Cinema**: This mode optimizes video for watching movies.
- **Sport**: This is the video mode to emphasize dynamic video and primary color (Ex, white, uniform, grass, sky blue etc.) by realizing the optimal screen for sports.
- **Game**: This is the mode to realize fast response speed in a fast gaming screen.
- **Expert**: This is the mode to adjust the video in detail for video quality expert and general user.
- THX Cinema (Only for 50/60PS60): This is cinema quality mode to provide you the experience of watching a movie at home. The user will be able enjoy the best level of satisfactory screen quality in any movie without any separate adjustments. THX Cinema expresses the optimal screen quality when it is darkest.
- When selecting THX **Cinema**, Aspect ratio changes to Just scan.

- THX (Thomlinson Holman's Experiment) is the audio and video certification standard of THX established by George Lucas and Thomlinson.
  This is the product to be certified in THX display area and guarantees screen quality that exceeds the display standard specification in both hardware and software.

MANUAL PICTURE ADJUSTMENT-USER MODE

Adjust the picture appearance to suit your preference and viewing situations.
50/60PS60 only: This feature is disabled in "**Picture Mode- THX Cinema**".



1 MENU Select **PICTURE**.

2 ENTER Select **Picture Mode**.

3 ENTER Select **Vivid**, **Standard**, **Cinema(or THX Cinema)**, **Sport**, or **Game**.

4 ENTER Select **Contrast**, **Brightness**, **Sharpness**, **Color**, or **Tint**.

5 ENTER Make appropriate adjustments.

6 RETURN Return to the previous menu.

MENU Return to TV viewing.

- **Contrast**: Increase or decrease the gradient of the video signal. You may use Contrast when the bright part of picture is saturated.
- **Brightness**: Adjusts the base level of the signal in the picture. You may use brightness when the dark part of the picture is saturated.
- **Sharpness**: Adjusts the level of crispness in the edges between the light and dark areas of the picture. The lower the level, the softer the image.
- **Color**: Adjusts intensity of all colors.
- **Tint**: Adjusts the balance between red and green levels.

PICTURE IMPROVEMENT TECHNOLOGY

You can calibrate the screen for each Picture Mode or set the video value according to the special video screen.
You can set the video seeing differently for each input.
To reset to the factory default screen after making adjustments to each video mode, execute the “Reset” function for each Picture Mode.



1 MENU Select **PICTURE**.

2 ENTER Select **Advanced Control**.

3 ENTER Select your desired options.

4 Make appropriate adjustments.

5 RETURN Return to the previous menu.

MENU Return to TV viewing.

EXPERT PICTURE CONTROL

By segmenting categories, **Expert1** and **Expert2** provide more categories which users can set as they see fit, offering the optimal picture quality for users.
This may also be used be a professional to help optimize the TV performance in the environment the TV is in.



1 MENU Select **PICTURE**.

2 ENTER Select **Picture Mode**.

3 ENTER Select **Expert1**, or **Expert2**.

4 ENTER Select **Expert Control**.

5 ENTER Select your desired menu option.

6 Make appropriate adjustments.

7 RETURN Return to the previous menu.

MENU Return to TV viewing.

Color Temperature	■ Set to warm to enhance hotter colors such as red, or set to cool to make picture bluish.
Dynamic Contrast	■ Adjusts the contrast to keep it at the best level according to the brightness of the screen. The picture is improved by making bright parts brighter and dark parts darker.
Dynamic Color	■ Adjusts screen colors so that they look livelier, richer and clearer. This feature enhances hue, saturation and luminance so that red, blue, green and white look more vivid.
Noise Reduction	■ Reduces screen noise without compromising video quality.
Gamma	*Low : Make dark and middle gray level area of the picture brighter.* *Medium: Express original picture levels.* *High: Make dark and middle gray level area of the picture darker.* ■ You can adjust brightness of dark area and middle gray level area of the picture.
Black Level	*Low: The reflection of the screen gets darker.* *High: The reflection of the screen gets brighter.* *Auto: Realizing the black level of the screen and set it to High or Low automatically.* ■ Set black level of the screen to proper level. ■ This function enables to select 'Low' or 'High' in the following mode: AV (NTSC-M), HDMI or Component. Otherwise, 'Black level' is set to 'Auto'.
Film Mode	■ Makes video clips recorded in film look more natural by eliminating judder effect. ■ DVD and Blu-ray movies are filmed at 24 frames per second.

Color Gamut	*Standard: Displays standard color area.* *Wide: Mode to use and set the rich color area of the display.* ■ Maximize the utilization of color to increase color quality. ■ This feature is enabled in "**Color Temperature - Warm**".
Edge Enhancer	■ Show clearer and distinctive yet natural corners of the video.
Color Standard	■ Convert the color of a different video to HD color.
White Balance	■ This is the function to adjust the overall color of the screen to the feeling you want. a. Method : 2 Points - Pattern: Inner, Outer - Red/Green/Blue Contrast, Red/Green/Blue Brightness: The adjustment range is -50 - +50. b. Method : 20 Point IRE - Pattern: Inner, Outer - IRE (Institute of Radio Engineers) is the unit to display the size of the video signal and can be set among 5, 10, 15 - 95, 100. You can adjust Red, Green or Blue according to each setting. - Red/Green/Blue: The adjustment range is -50 - +50.
Color Management System	■ As the tool used by the experts to make adjustments by using the test patterns, this does not affect other colors but can be used to selectively adjust the 6 color areas (Red/Green/Blue/Cyan/Mgt/Yellow). Color difference may not be distinctive even when you make the adjustments for the general video. Adjusts Red/Green/Blue/Yellow/Cyan, Magenta. - Red/Green/Blue/Yellow/Cyan, Magenta Color: The adjustment range is -30 - +30. - Red/Green/Blue/Yellow/Cyan, Magenta Tint: The adjustment range is -30 - +30. - This feature is disable in RGB-PC and HDMI (PC) mode.

PICTURE RESET

Settings of the selected picture modes return to the default factory settings.



1 MENU Select **PICTURE**.

2 ENTER Select **Reset**.

3 ENTER Initialize the adjusted value.

4 MENU Return to TV viewing.

IMAGE STICKING MINIMIZATION (ISM) METHOD

A frozen still picture displayed on the screen for prolonged periods can result in a ghost image. You can use Orbiter to help prevent image sticking. The other two functions are for removing a ghost image.



1 MENU Select **OPTION**.

2 ENTER Select **ISM Method**.

3 ENTER Select **Normal, Orbiter, Color Wash** or **White Wash.**

4 RETURN Return to the previous menu.

MENU Return to TV viewing.

- **Normal**: If image sticking is never a problem, ISM is not necessary - set to Normal.
- **Orbiter**: Orbiter may help prevent ghost images. However, it is best not to allow any fixed image to remain on the screen. To avoid a ghost image on the screen, the image will move every 2 minutes.
- **Color Wash**: The color block with the screen moved a little and the white pattern are alternately displayed. It is difficult to see the after image on all colors. Once it has been corrected it will not be visible in any color.
- **White Wash**: White Wash removes ghost images from the screen. Use sparingly. Watch the TV normally for a while before using this feature to see if the ghost image disappears on its own.

NOTE

G An excessive ghosted image may be impossible to clear entirely with White Wash. To return to normal viewing, press the any button.

DEMO MODE

Displays a slide show to explain the various features of this TV.
This feature is disabled in "**Initial Setting-Home Use**".



1 

Select **OPTION**.

2 

Select **Demo Mode**.

3 

Select **On**.

4 

Return to TV viewing.

After a while, **Demo Mode** starts.
If you want to stop the demo, press any button.
(except VOL or MUTE)

5 Show the various features of the TV.

6 Show the difference XD Engine features.

SOUND & LANGUAGE CONTROL

AUTO VOLUME LEVELER (AUTO VOLUME)

Auto Volume makes sure that the volume level remains consistent whether you are watching a commercial or a regular TV program.

Because each broadcasting station has its own signal conditions, volume adjustment may be needed every time the channel is changed. This feature allows users to enjoy stable volume levels by making automatic adjustments for each program.



1 MENU Select **AUDIO**.

2 ENTER Select **Auto Volume**.

3 ENTER Select **On** or **Off**.

4 RETURN Return to the previous menu.

MENU Return to TV viewing.

CLEAR VOICE II

By differentiating the human sound range from others, it improves the sound quality of voices.



1 MENU Select **AUDIO**.

2 ENTER Select **Clear Voice II**.

3 ENTER Select **On** or **Off**.

■ If you select "**Clear Voice II-On**", **SRS TruSurround XT** feature will not work.

Adjustment for Clear Voice II Level With selecting On

4 ENTER Select **Level**.

5 ENTER Make appropriate adjustments.

6 RETURN Return to the previous menu.

MENU Return to TV viewing.

PRESET SOUND SETTINGS (SOUND MODE)

Sound Mode lets you enjoy the best sound without any special adjustment as the TV sets the appropriate sound options based on the program content.

Standard, **Music**, **Cinema**, **Sport**, and **Game** are preset for optimum sound quality at the factory and are not adjustable.



---

1 Q. MENU

Select **Sound Mode**.

2

Select **Standard**, **Music**, **Cinema**, **Sport**, or **Game**.

3 Q. MENU

Return to TV viewing.

- You can also adjust **Sound Mode** in the **AUDIO** menu.
- **Standard**: Offers standard-quality sound.
- **Music**: Optimizes sound for listening to music.
- **Cinema**: Optimizes sound for watching movies.
- **Sport**: Optimizes sound for watching sports events.
- **Game**: Optimizes sound for playing games.

SOUND SETTING ADJUSTMENT - USER MODE

Adjust the sound to suit your taste and room situations.



1 MENU — Select **AUDIO**.

2 ENTER — Select **Sound Mode**.

3 ENTER — Select **Standard**, **Music**, **Cinema**, **Sport**, or **Game**.

4 ENTER — Select **Treble** or **Bass**.

5 ENTER — Make appropriate adjustments.

6 RETURN — Return to the previous menu.

MENU — Return to TV viewing.

SRS TRUSURROUND XT

Select this option to sound realistic.

1 MENU — Select **AUDIO**.

2 ENTER — Select **SRS TruSurround XT**.

3 ENTER — Select **On** or **Off**.

4 RETURN — Return to the previous menu.

MENU — Return to TV viewing.

- If you select "**Clear Voice II-On**", **SRS TruSurround XT** feature will not work.
- **SRS TruSurround XT**: TruSurround XT is a patented SRS technology that solves the problem of playing 5.1 multichannel content over two speakers.

BALANCE

Adjust the left/right sound of speaker to suit your taste and room situations.



1 MENU Select **AUDIO**.

2 ENTER Select **Balance**.

3 ENTER Make appropriate adjustments.

4 RETURN Return to the previous menu.

MENU Return to TV viewing.

TV SPEAKERS ON/OFF SETUP

Turn the TV speakers off if using external audio equipment.
If you wish to use an external Hi-Fi system or a SRS system, turn off the TV's internal speakers.



1 MENU Select **AUDIO**.

2 ENTER Select **TV Speaker**.

3 ENTER Select **On** or **Off**.

4 RETURN Return to the previous menu.

MENU Return to TV viewing.

AUDIO RESET

Settings of the selected Sound Mode return to the default factory settings.



1 MENU Select **AUDIO**.

2 ENTER Select **Reset**.

3 ENTER Initialize the adjusted value.

4 MENU Return to TV viewing.

STEREO/SAP BROADCAST SETUP

For Analog only: This TV can receive MTS stereo programs and any SAP (Secondary Audio Program) that accompanies the stereo program if the station transmits an additional sound signal. Mono sound is automatically used if the broadcast is only in Mono.



Analog TV

1 Q. MENU  Select **SAP**.

2  Select **Mono**, **Stereo**, or **SAP**.

3 Q. MENU Return to TV viewing.

Digital TV

1 Q. MENU  Select **Multi Audio**.

2  Select other languages.

3 Q. MENU Return to TV viewing.

AUDIO LANGUAGE

Other languages may be available if a digital signal is provided by the broadcasting station.
This feature operates only in DTV/CADTV mode.



1 MENU Select **OPTION**.

2 ENTER Select **Audio Language**.

3 ENTER Select your desired language.

4 RETURN Return to the previous menu.

MENU Return to TV viewing.

ON-SCREEN MENUS LANGUAGE SELECTION

The menus can be shown on the screen in the selected language.



1 MENU Select **OPTION**.

2 ENTER Select **Menu Language(Language)**.

3 ENTER Select your desired language.
From this point on, the on-screen menus will be shown in the selected language.

4 RETURN Return to the previous menu.

MENU Return to TV viewing.

CAPTION MODE

Analog Broadcasting System Captions

Captions are provided to help people with hearing loss watch TV. Select a caption mode for displaying captioning information if provided on a program. Analog caption displays information at any position on the screen and is usually the program's dialog. Caption/Text, if provided by the broadcaster, would be available for both digital and analog channels on the Antenna/Cable. This TV is programmed to memorize the caption/text mode which was last set when you turned the power off. This function is only available when **Caption** Mode is set **On**.



1 MENU Select **OPTION**.

2 ENTER Select **Caption**.

3 ENTER Select **On**.

4 Select **CC1-4** or **Text1-4**.

5 RETURN Return to the previous menu.

MENU Return to TV viewing.

- When selecting **Off**, Sub-menus for Analog, DTV, and Digital Option become disabled.
- **CAPTION**
  The term for the words that scroll across the bottom of the TV screen; usually the audio portion of the program provided for the hearing impaired.
- **TEXT**
  The term for the words that appear in a large black frame and almost cover the entire screen; usually messages provided by the broadcaster.

Digital Broadcasting System Captions

Choose the language you want the DTV/CADTV Captions to appear in.
Other Languages can be chosen for digital sources only if they are included on the program.
This function in only available when **Caption** Mode is set **On**.



1 MENU Select **OPTION**.

2 ENTER Select **Caption**.

3 ENTER Select **On**.

4 Select **CC1-4**, **Text1-4**, or **Service1 - 6**.

5 RETURN Return to the previous menu.

MENU Return to TV viewing.

Caption Option

Customize the DTV/CADTV captions that appear on your screen.
This function in only available when **Caption** Mode is turned **On**.



1 MENU Select **OPTION**.

2 ENTER Select **Caption**

3 ENTER Select **On**.

4 Select **Digital Option**.

5 ENTER Select **Custom**.

6 Customize the **Style**, **Font**, etc., to your preference. A preview icon is provided at the bottom of the screen, use it to see the caption language.

7 RETURN Return to the previous menu.

MENU Return to TV viewing.

- **Size**: Set the word size.
- **Font**: Select a typeface for the text.
- **Text Color**: Choose a color for the text.
- **Text Opacity**: Specify the opacity for the text color.
- **Bg (Background) Color**: Select a background color.
- **Bg (Background) Opacity**: Select the opacity for the background color.

TIME SETTING

CLOCK SETTING

Auto Clock Setup

The time is set automatically from a digital channel signal.
The digital channel signal includes information for the current time provided by the broadcasting station.
Set the clock manually if the current time is set incorrectly by the auto clock function.



1 MENU — Select **TIME**.

2 ENTER — Select **Clock**.

3 ENTER — Select **Auto**.

4 — Select your viewing area time zone.
- U.S.A: **Eastern**, **Central**, **Mountain**, **Pacific**, **Alaska**, or **Hawaii**.
- Canada: **Eastern**, **Central**, **Mountain**, **Pacific**, **New F.land**, or **Atlantic**.

5 — Select **Auto**, **On**, or **Off** (depending on whether or not your viewing area observes Daylight Saving time).

6 RETURN — Return to the previous menu.

MENU — Return to TV viewing.

Manual Clock Setup

If the current time setting is wrong, set the clock manually.



1 MENU Select **TIME**.

2 ENTER Select **Clock**.

3 ENTER Select **Manual**.

4 Select the Year, Month, Date, Hour, or Minutes option.

5 Set the Year, Month, Date, Hour, or Minutes option.

6 RETURN Return to the previous menu.

MENU Return to TV viewing.

G If you unplug the TV once or turn the main power off, the clock function reset.

AUTO ON/OFF TIME SETTING

This function operates only if the current time has been set.
The **Off Time** function overrides the **On Time** function if they are both set to the same time.
The TV must be in standby mode for the **On Time** to work.
If you do not press any button within 2 hours after the TV turns on with the **On Time** function, the TV will automatically revert to standby mode.



1 MENU Select **TIME**.

2 ENTER Select **Off time** or **On time**.

3 ENTER Select **Repeat**.

4 Select **Off**, **Once**, **Daily**, **Mon.~Fri.**, **Mon.~Sat.**, **Weekend**, or **Sunday**.

5 Select and set **Hour** or **Minute**.

6 RETURN Return to the previous menu.

MENU Return to TV viewing.

- To cancel **On/Off Time** function, select **Off**.
- Only for On Time function

1 ENTER Select **Input**.

2 Select the desired input source.

3 When Selecting **TV**: set the channel at turn-on.

4 Adjust to sound level at turn-on.

SLEEP TIMER SETTING

The Sleep Time turns the TV off at the preset time.
Note that this setting is cleared when the TV is turned off.



1 Q. MENU Select **Sleep Timer**.

2  Select **Off**, **10**, **20**, **30**, **60**, **90**, **120**, **180**, or **240** minutes.

3 Q. MENU Return to TV viewing.

■ You can also adjust **Sleep Timer** in the **TIME** menu.